



ELEVATOR

PART LIST (Trim)

PART	QTY	S / N	DESCRIPTION
1	1	6-T-6-1	Trim tab skin
2	1	6-T-6-4	Piano hinge trim
3	1	6-T-6-6	Trim tab horn angle
PART	QTY	S / N	DESCRIPTION
4	1	6-T-3-2	Elevator centre channel
5	2	6-T-3-1L	Right elevator rib
6	1	6-T-3-1R	Left elevator rib
7	1	6-T-3-8	Elevator connection strip
8	1	6-T-3-7	Elevator longeron reinforcemnt
9	1	6-T-3-6	Elevator lver connection extr. angular
10	1	6-T-2-5	Piano hinge elevator
11	1	6-T-3-3trim	Elevator skin
12	1	6-T-3-1Ltrim	Left trim elevator trim
13	1	6-T-6-5	Access hole cover plate
14	1	6-T-3-4mod	Upper elevator horn
15	1	6-T-3-4E	Extr. upper elevator horn
16	1	6-T-3-5mod	Lower elevator horn
17	1	6-T-3-5E	Extr. lower elevator horn
18	2	6-T-3-9	Elevator rear longeron angle
19	1	6-T-3-10	Upper elevator lever doubler
20	1	6-T-3-11	Lower doubler elevator lever
21	1	6-T-3-1Rint	Inner right elevator rib
22	1	6-T-3-1Lint	Inner left elevator rib
23	1	6-T-6-7	"L" trim angle
24	1	6-T-6-3	Elevator trim cutout channel
26	1		Motorino Ray Allen
27	1	6-T-6-50	Asta lunga per ABT / Long rod for ABT
28	2	6-T-3-50	